

---

## BendPak Technical Service Bulletin

# Four-Post Lifts – Lubricating the Cable Sheaves


### BendPak TSB 84-122021

This Technical Service Bulletin describes the Lubrication Points on a BendPak Four-Post Lift that **must** be properly greased **prior** to Lift operation. There are several lubrication points on a BendPak Four-Post Lift; all of them are where Cable Sheaves are located: under the Powerside Runway and on the Crosstube Gussets.

**Important:** BendPak Four-Post Lifts work better and longer if you keep them lubricated.

Place a generous amount of red lithium grease or similar on each Cable Sheave Bore and Cable Sheave Pin. Repeat monthly or as needed.

The arrows below indicate the Cable Sheave locations on a BendPak Four-Post Lift.



If you have questions about your BendPak Four Post Lift, go to [Bendpak.com/support](https://www.bendpak.com/support), email [support@bendpak.com](mailto:support@bendpak.com), or call (800) 252-2363.