


## BendPak Technical Service Bulletin RCD-2V – Installation and Operation Manual Revision

### BendPak TSB 152 - 112024

This Technical Service Bulletin describes a required change to nomenclature for caster in the manual for the RCD-2V Vehicle Dolly. This TSB applies to RCD-2V Vehicle Dolly shipped with the Installation and Operation Manual RCD-2V - 5900932 - Rev. B - Dec 2018.


The RCD-2V Vehicle Dolly ships with four (4) total casters – two (2) are Swivel Casters, and two (2) are Swivel Lockable Casters.

In previous versions of the manual, there were several different nomenclatures used to describe this, which could have led to customer confusion in the field; on page 5 of that manual, the Components illustration is superseded by this version of the illustration:



Similarly on page 7 of that manual, the Parts Breakdown illustration is superseded by this version of the illustration:

## Parts Breakdown



Num	Description	Qty
1	Support Adaptor	2
2	Support Beam	2
3	Nut M12	2
4	Knob	2
5	Washer M10	26
6	Spring Washer M10	26
7	Bolt M10 x 25	24
8	Bolt M6 x 10	4
9	Spring Washer M6	4
10	Adaptor Base	2
11	Block	2
12	Main Beam	1

Num	Description	Qty
13	Support Beam	2
14	Swivel Caster	2
15	Nut M10	26
16	Swivel Lockable Caster	2
17	Bolt M10 x 70	2
18	Bolt M10 x 30	4
19	Side Board 2	2
20	Rubber	2
21	Spring	6
22	Busher	6
23	Side Board 1	2
24	R Pin	4

If you experience difficulties with your RCD-2V Vehicle Dolly, technical support and service is available from your dealer, on the Web at [bendpak.com/support](http://bendpak.com/support), by email at [support@bendpak.com](mailto:support@bendpak.com), or by phone at **(800) 253-2363**, follow the prompts to reach service.

Online chat is also available at [www.bendpak.com](http://www.bendpak.com)



30440 Agoura Road  
 Agoura Hills, CA 91301 USA  
 Toll Free: 1(800) 253-2363  
 Tel: 1 (805) 933-9970  
[rangerproducts.com](http://rangerproducts.com)